



2. 54016-47 HOOD ASSY  
 26028-1 BELT WINDOW  
 37433-12 FURNITURE GUARD

7. 54340-1 BASE ASSY  
 55970 FELT GASKET  
 55968 FELT GASKET  
 55971 FELT GASKET  
 38063 BELT GUARD

NOT ILLUSTRATED  
 57421-1 WIRE & TERMINAL ASSY  
 38156 MOTOR STRAP  
 38177 MOTOR SHIELD  
 27058-2 SWITCH BRACKET  
 13738-9 SWITCH ASSY  
 26474-2 SWITCH PEDAL

37. 53411-1 DISTURBULATOR ASSY COMPLETE  
 52988-3 BRISTLE STRIP SET  
 13650-1 DISTURBULATOR TUBE  
 52995 BEARING ASSY  
 37441 DISTURBULATOR CAP  
 53158 LOCKNUT  
 53167 SHAFT WASHER  
 37441 DISTURBULATOR CAP  
 52995 PULLEY & BEARING ASSY  
 52995 SHAFT

27. 56233-1 HANDLE SOCKET ASSY  
 55974 LATCH INSERT

| Ref # | Part     | Description               | Comments | Qty |
|-------|----------|---------------------------|----------|-----|
| 1     | 13650-1  | TUBE - DISTURBULATOR      |          |     |
| 2     | 13738-9  | SWITCH ASSEMBLY           |          |     |
| 3     | 26028-1  | WINDOW - BELT             |          |     |
| 4     | 26467-1  | COVER - AIR DUCT          |          |     |
| 5     | 26474-2  | PEDAL - SWITCH            |          |     |
| 6     | 27058-2  | BRACKET - SWITCH          |          |     |
| 7     | 27672-14 | POLARIZED CORD & PLUG ASS |          |     |
| 8     | 37433-12 | GUARD - FURNITURE         |          |     |
| 9     | 37434-2  | WHEEL - REAR              |          |     |
| 10    | 37441    | DISTURBULATOR CAP         |          |     |
| 11    | 38063    | GUARD - BELT              |          |     |
| 12    | 38156    | STRAP - MOTOR             |          |     |
| 13    | 38177    | SHIELD - MOTOR            |          |     |
| 14    | 38310-1  | STRAIGHT WAND ASSY        |          |     |
| 15    | 52201A   | BELT PACKAGE ASSY - STYLE |          |     |
| 16    | 52988-3  | BRISTLE STRIP SET         |          |     |
| 17    | 52995    | DISTURBULATOR REPAIR KIT  |          |     |
| 18    | 53158    | LOCK NUT PACKAGE          |          |     |
| 19    | 53167    | WASHER - SHAFT PACKAGE    |          |     |
| 20    | 53190-1  | BUSHING - STRAIN RELIEF-P |          |     |
| 21    | 53238-18 | SCREW PACKAGE             |          |     |
| 22    | 53238-19 | SCREW PACKAGE             |          |     |
| 23    | 53238-8  | SCREW PACKAGE             |          |     |
| 24    | 53411-1  | DISTURBULATOR ASSY - CRTN |          |     |
| 25    | 54016-47 | POWERHEAD HOOD ASSY - PAC |          |     |
| 26    | 54340-1  | KIT - POWER HEAD BASE ASS |          |     |
| 27    | 54343-1  | MOTOR ASSEMBLY - PACKAGED |          |     |
| 28    | 55968    | GASKET - FELT             |          |     |
| 29    | 55970    | GASKET - FELT             |          |     |
| 30    | 55971    | GASKET - FELT             |          |     |
| 31    | 55974    | INSERT - LATCH            |          |     |
| 32    | 55979    | SPRING STRAP              |          |     |
| 33    | 55980-1  | STRAP                     |          |     |
| 34    | 56180    | FELT WASHER               |          |     |
| 35    | 56233-1  | HANDLE SOCKET ASSEMBLY    |          |     |
| 36    | 56489    | AXLE                      |          |     |
| 37    | 56824    | WHEEL & SLEEVE ASSEMBLY   |          |     |
| 38    | 57421-1  | WIRE & TERMINAL ASSEMBLY  |          |     |
| 39    | 60192-1  | WIRE SPLICE 5             |          |     |